

Q-FORMS INSTALLATION TIPS**NOTE: ALWAYS CHECK FIT OF Q-FORMS INTO THE VEHICLE BEFORE ANY CUTTING OR MODS ARE DONE!!**

QL-K1001	1-1/2" PARKING BRAKE BEND REQUIRED.
QL-K1002	USE SUPPLIED SECONDARY PLASTIC TRIM PIECE TO CONNECT Q-FORM AND SCUFF PLATE.
QL-K1003	USE SUPPLIED PLASTIC HOUSING AND TRIM PATTERN FOR MODELS WITH A/C.
QL-K1004	1-1/2" PARKING BRAKE BEND REQUIRED.
QL-K1005	REQUIRES CUTTING OF THE FACTORY PIECE SO THAT IT CAN BE JOINED WITH THE Q-FORM.
QL-K1006	Q-FORM MOUNTS ON TOP OF FACTORY KICK PANEL IF EQUIPPED.
QL-K1007	1-1/2" PARKING BRAKE BEND REQUIRED.
QL-K1008	WILL NOT FIT CONVERTIBLE MODELS.
QL-K1009	REQUIRES CUTTING OF THE FACTORY PIECE SO THAT IT CAN BE JOINED WITH THE Q-FORM.
QL-K1010	
QL-K1011	1-1/2" PARKING BRAKE BEND REQUIRED. SOME MODELS REQUIRE RELOCATION OF FACTORY COMPUTER.
QL-K2001	WILL NOT FIT CONVERTIBLE MODELS.
QL-K2003	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K2005	1-1/2" PARKING BRAKE BEND REQUIRED.
QL-K2008	REQUIRES RELOCATION OF THE HOOD RELEASE TO THE UNDERSIDE OF THE DASH
QL-K2009	1/2" PARKING BRAKE BEND REQUIRED.
QL-K2010	1/2" PARKING BRAKE BEND REQUIRED.
QL-K2012	REQUIRES REMOVAL OF FACTORY FOOTREST on SVT3 Model

QL-K3001	1-1/2" PARKING BRAKE BEND REQUIRED. CUT FACTORY PIECE TO JOIN WITH Q-FORM.
QL-K3002	RESTS CLOSE TO CLUTCH.(MANUAL TRANSMISSIONS)
QL-K3003	USE OF FACTORY FOOTREST IS LOST.
QL-K3004	USE OF FACTORY FOOTREST IS LOST.
QL-K3005	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K3006	
QL-K3007	3/4" PARKING BRAKE BEND REQUIRED.
QL-K3008	3/4" PARKING BRAKE BEND REQUIRED.
QL-K3009	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K3010	
QL-K3012	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K4002	USE OF FACTORY FOOTREST IS LOST. FITS AROUND FACTORY COMPUTER AND HOLD SEPARATES.
QL-K4003	USE OF FACTORY FOOTREST IS LOST.
QL-K4004	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K4005	
QL-U5001	UNIVERSAL PANELS HOLDS UP TO 6-1/4" SEPARATES.
QL-K6001	REQUIRES REMOVAL OF FACTORY FOOTREST. CUT FACTORY PIECE TO JOIN WITH Q-FORM.
QL-K6002	REQUIRES REMOVAL OF FACTORY FOOTREST AND PLASTIC HOOD RELEASE HOUSING.
QL-K6003	REQUIRES REMOVAL OF FACTORY FOOTREST.

QL-K6004	REQUIRES REMOVAL OF FACTORY FOOTREST. SOME MODELS REQUIRE RELOCATION OF FACTORY CPM.
QL-K6005	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K6006	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K6007	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K6008	REQUIRES REMOVAL OF FACTORY FOOTREST. REQUIRES RELOCATION OF HOOD RELEASE LEVER, Bracket Provided
QL-K7001	REQUIRES REMOVAL OF FACTORY FOOTREST. SOME MODELS REQUIRE RELOCATION OF FACTORY CPM.
QL-K8001	RESTS CLOSE TO CLUTCH.(MANUAL TRANSMISSIONS)
QL-K9001	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K1101	1/2" PARKING BRAKE BEND REQUIRED.
QL-K1201	REQUIRES RELOCATION OF HOOD RELEASE LEVER AND FACTORY WIRE HARNESS IN PASS. KICK PANEL.
QL-K1202	REQUIRES REMOVAL OF FACTORY FOOTREST.
QL-K1203	REQUIRES REMOVAL OF FACTORY FOOTREST.